



GEMMA LINE GOLD

Induction Hobs

Code: I439 N19

TABLE CUISSON INDUCTION GEMMA LIGNE INOX



DETAILS

Coloring	Gold
Kind of Edge	Full - h 4mm
Material	AISI 304 stainless steel
Material	Ceramic glass
Thickness	4 mm
Supply	230 - 380 V (50/60 Hz)
Dimensions	1080x490 mm
Full description	Quadra Modular Composition - 3 fields - black
Heating element	Three zones



Built-in hole	View technical data sheet
Width	108 cm
Notes:	Connection box included
Total power	6.700 W
Left	2.300 (3.000)* W
Centre	1.100 (1.400)* W
Right	2.300 (3.000)* W
Power settings	9 power settings per zone + Powerboost
Safety	Safety equipment
Туре	Induction Hob
Type of commands	Touch Control
Notes:	* Powerboost
Power settings Safety Type Type of commands	9 power settings per zone + Powerboost Safety equipment Induction Hob Touch Control

FEATURES

Powerboost


Booster function provides increased power to the selected plate. In particular, when the Booster is activated, the plate works for ten minutes at a very high power that allows to heat quickly large quantities of water.




Pot detector	All induction cooker hobs detect the pot resting on them, but they also calculate the area they cover. This system allows the energy to be used even more efficiently. Moreover, the plates switch off automatically when the pot is removed.
Smart fan system	Correct ventilation is essential for the induction hob to function in the best possible way. The Foster system automatically regulates the amount of ventilation to suit the temperatures reached.
End-of-cooking programming	All operations are programmed by means of the touch-control on the glass itself. Each cooking plate is capable of independent programming, and thus the possibility to set different cooking times.
Slider commands	The Slider control allows for extremely quick temperature setting: with a light touch of the finger you may select the desired power level on the TOUCH display.
Timer	Indipendent timer from the end-of-cooking function.
Heat maintenance	Function that allows the food to be kept warm gently (70° C), without reaching boiling temperatures or risking to burn the sauce.
Go&stop function	This device initially turns on the plates at maximum power until the selected temperature has been reached.
Recall	This feature allows you to call back the last settings selected in the previous cooking.
Pause	Useful function that allows you to distract your attention from cooking, interrupting and restoring the settings immediately.
Safety	All electric cooker hobs feature the most modern and sophisticated safety protections: Centralised power-off function; Child-proof safety lock; Residual heat warning lights. Induction models feature the following functions: Safety System that turn off the hob in the absence of the pot; Overflow detector that automatically turns off the plate in case of liquid overflow; Automatic deactivation to prevent accidents caused by forgetfulness.

TECHNICAL DATA

Foster ==




Foster ==



FTS - cut out

FT - cut out





RECOMMENDED PAIRINGS



SUPPORT DE PRISE VERSO GOLD
A000 A19